



Devices	EN54 Fire Hub Jeweller	Hub (2G) Jeweller	Hub (4G) Jeweller	Hub 2 (2G) Jeweller	Hub 2 (4G) Jeweller	Hub 2 Plus Jeweller	Hub BP Jeweller	Hub BP Jeweller (without casing)	Hub Plus Jeweller	Superior Hub G3 Jeweller	Superior Hub Hybrid (2G)	Superior Hub Hybrid (4G)	Superior Hub Hybrid (4G) (without casing)	Superior Hub Hybrid 2	Superior Hub Hybrid 2 (without casing)	Superior MegaHub	Superior MegaHub (without casing)	Type4 Fire Hub Jeweller	Type4 Hub (4G) Jeweller	EN54 Fire ReX Jeweller	ReX 2 Jeweller	ReX Jeweller	Superior ReX G3 Jeweller	Type4 Fire ReX Jeweller	Type4 ReX Jeweller
Keypads																									
KeyPad Jeweller	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	—	—	✔	✔	✔	✔	—	—
KeyPad Outdoor Jeweller	✔	—	—	✔	✔	✔	✔	✔	—	✔	✔	✔	✔	✔	✔	✔	✔	—	—	✔	✔	✔	✔	—	—
KeyPad Plus Jeweller	✔	—	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	—	—	✔	✔	✔	✔	—	—
KeyPad TouchScreen Jeweller	✔	—	—	✔	✔	✔	✔	✔	—	✔	✔	✔	✔	✔	✔	✔	✔	—	—	✔	✔	—	✔	—	—
Superior KeyPad Fibra	—	—	—	—	—	—	—	—	—	—	✔	✔	✔	✔	✔	✔	✔	—	—	—	—	—	—	—	—
Superior KeyPad Outdoor Fibra	—	—	—	—	—	—	—	—	—	—	✔	✔	✔	✔	✔	✔	✔	—	—	—	—	—	—	—	—
Superior KeyPad Plus G3 Jeweller	✔	—	—	✔	✔	✔	✔	✔	—	✔	✔	✔	✔	✔	✔	✔	✔	—	—	✔	✔	✔	✔	—	—
Superior KeyPad Plus Jeweller	✔	—	—	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	—	—	✔	✔	✔	✔	—	—
Superior KeyPad TouchScreen Fibra	—	—	—	—	—	—	—	—	—	—	✔	✔	✔	✔	✔	✔	✔	—	—	—	—	—	—	—	—
Superior KeyPad TouchScreen G3 Jeweller	✔	—	—	✔	✔	✔	✔	✔	—	✔	✔	✔	✔	✔	✔	✔	✔	—	—	✔	✔	—	✔	—	—

