

Superior Internal Battery user manual

Updated January 28, 2026



Superior Internal Battery is a rechargeable Li-ion battery designed for powering **Superior Hub G3 Jeweller** and **Superior ReX G3 Jeweller**. The battery is available in two versions:

1. **Superior Internal Battery (16h)**. It provides up to 16 hours of autonomous operation for the device.
2. **Superior Internal Battery (60h)**. It provides up to 60 hours of autonomous operation for the device.

- › **Buy Superior Internal Battery (16h)**
- › **Buy Superior Internal Battery (60h)**
- › **Buy Superior Hub G3 Jeweller**

Compatible hubs and range extenders

The battery requires a compatible Ajax hub or range extender to operate.

[Check device compatibility.](#)

Operating principle

Superior Internal Battery (16h) and Superior Internal Battery (60h) are internal rechargeable batteries used as a backup power source for the Ajax hub and range extender.

Selecting an installation site

The battery must be installed only inside the Superior Hub G3 Jeweller or Superior ReX G3 Jeweller enclosure. When selecting the hub or range extender location, consider the factors that affect the battery operation:

- Operating temperature range.
- Permissible humidity level.

Consider the placement recommendations when designing your Ajax system. Only professionals must design and install the system. The list of recommended Ajax partners is [available here](#).

Where not to install the battery

1. In places with high temperatures. For example, near heat sources, such as radiators, heaters, direct sunlight, etc. High temperatures can cause battery overheating, rapid self-discharge, damage to its components, and even explosion or fire.
2. In places with high humidity. Moisture can corrode the contacts or cause a short circuit.

3. Near flammable materials. Never place the battery near flammable liquids or materials. Doing so increases the risk of fire or explosion, especially if a short circuit occurs.

Installation

Before installing the battery, ensure that you have selected the optimal hub or range extender location and read the [Superior Hub G3 Jeweller](#) or [Superior ReX G3 Jeweller](#) user manuals. It is recommended to install the battery when the hub or range extender is turned off, and its external power supply is disconnected.



During Ajax system installation and operation, follow the rules and requirements of regulatory legal acts on electrical safety.

Do not dismantle, open, or shred secondary cells or batteries. Do not insert your fingers, hands, or foreign objects into any battery gaps or openings, such as vents, terminals, etc.




Superior Hub G3 Jeweller and Superior ReX G3 Jeweller have a similar enclosure, so the battery installation process is the same for both devices.

Installing the battery

1. Remove the SmartBracket mounting panel from the device. First, unscrew the holding screws and slide the panel down.
2. Insert the battery into the backup battery slot inside the device so that the connectors align.



3. Slide the battery up until the latches secure it in place.




4. Install the device on the SmartBracket mounting panel.

5. Check the **Battery charge** state in the device **states** in an Ajax app.



Removing the battery

1. Remove the SmartBracket mounting panel from the device. First, unscrew the holding screws and slide the panel down.
2. Press the latches down and slide the battery downward.



3. Remove the battery from the device enclosure.



States

The hub and range extender states include information about the battery status. These states can be found in [Ajax PRO app](#):

1. Go to the **Devices**  tab.
2. Select **Superior Hub G3 Jeweller** or **Superior ReX G3 Jeweller** from the list.

Maintenance

Superior Internal Battery (16h) and **Superior Internal Battery (60h)** do not require maintenance. They can be charged after being installed into the hub or range extender powered by the main power supply.



When the battery is low, recharge it as soon as possible to prevent battery degradation.



If the battery is not in use, it should be stored charged at a temperature not exceeding +30 °C. This is necessary to reduce battery degradation.

Technical specifications

[Buy Superior Internal Battery_\(16h\).](#)

[Buy Superior Internal Battery_\(60h\).](#)

[Compliance with standards](#)

Warranty

Warranty for the Limited Liability Company “Ajax Systems Manufacturing” products is valid for 2 years after the purchase.

If the device does not operate properly, we recommend contacting Ajax Technical Support first. In most cases, technical issues can be resolved remotely.

[Warranty obligations](#)

[User Agreement](#)

Contact Technical Support:

- [e-mail](#)
- [Telegram](#)

Manufactured by “AS Manufacturing” LLC



Need help?

Explore the full potential of an Ajax system through detailed manuals, articles, tools, and FAQs. For immediate assistance, our AI-powered chatbot and professional technical support team are available 24/7.

[Ask a question](#)

Subscribe

Subscribe to our emails about secure life. No spam.

[Subscribe](#)

Request extra help

- +447451279411
- support@ajax.systems
- @AjaxSystemsSupport_Bot
- Ask a question



Rating 4.8

4,500,000

people worldwide under Ajax protection

? Suggest a feature



Products


- Intrusion protection
- Video surveillance
- Fire and life safety
- Comfort and automation
- All products
- Services
- System integrations
- Ajax Ready products
- Fibra wired protocol
- Ajax radio protocols

Solutions

- Customer stories
- Solutions by facility type
- Commercial fire detection and alarm system
- Wireless Grade 3 solution
- Wired Grade 3 solution

Software

- Ajax Security System
- Ajax PRO: Tool for Engineers
- Ajax Desktop
- Ajax PRO Desktop
- Ajax TV
- Ajax Translator PRO
- Ajax Cloud Signaling
- Ajax Media Player
- Scenarios



Support

- Manuals and articles
- Compliance with standards

Tools

- Ajax kit configurator

[Video surveillance solution](#)
[Integration with Yale smart locks](#)
[Upgrades and retrofits](#)
[Why Ajax](#)
[How it works](#)

[Ajax device compatibility](#)
[CMS software compatibility](#)
[Ajax Services availability](#)
[Video storage calculator](#)
[Video device calculator](#)
[Battery life calculator](#)
[Radio communication range calculator](#)
[Switches and outlets configurator](#)
[Fibra power supply calculator](#)
[All web tools](#)

Monitoring solutions and integrations

[Intrusion alarm monitoring](#)
[Video monitoring and visual alarm verification](#)
[Audio alarm verification](#)

Company

[Blog](#)
[About us](#)
[Press page](#)
[Events](#)
[Career](#)
[Ajax Next](#)
[Ajax PRO channel](#)
[Reviews and feedback](#)

For partners

[For partners](#)
[Ajax Academy](#)
[Partner Portal](#)
[Ajax PRO channel](#)

 [United Kingdom](#) [Privacy policy](#) [Report a vulnerability](#) [GDPR White Paper](#) [NDAA Statement](#) [Cookie policy](#)
[Anti-Spam Policy](#) [Ajax Services T&C](#) [End user agreement](#) [Warranty](#)

© 2026 AJAX SYSTEMS CH. All rights reserved